

IMPORTANT BACKFILL NOTE:

ADD 2/3 CUPS PER CALIPER INCH OF MEDIUM
TEXTURE TERRA-SORB HYDROGEL TO TOP SIX
INCHES OF NATIVE SOIL BACKFILL MATERIAL.
THOROUGHLY MIX TERRA-SORB INTO BACKFILL.

MARK THE NORTH SIDE OF
THE TREE IN THE NURSERY,
AND ROTATE TREE TO FACE
NORTH AT THE SITE
WHENEVER POSSIBLE.

BEFORE PLANTING, IF ROOT
FLARE IS NOT VISIBLE, REMOVE
EXCESS SOIL FROM THE TOP
OF THE ROOT BALL UNTIL THE
ROOT FLARE IS EXPOSED

ONCE THE ROOT FLARE IS
EXPOSED, SET THE TOP OF
THE ROOT BALL 2" HIGHER
THAN ADJACENT GRADE

MULCH PLANTING PIT WITH 1"
DEPTH OF SHREDDED HARDWOOD
MULCH. KEEP MULCH 6" AWAY
FROM TREE TRUNK.

PLACE ROOT BALL ON
UNEXCAVATED SOIL SO
THAT ROOT BALL DOES
NOT SHIFT OR SETTLE.

NOTES:


- DO NOT HEAVILY PRUNE THE TREE AT TIME OF PLANTING.
- PRUNE ONLY CROSSOVER LIMBS, CO-DOMINANT LEADERS, AND BROKEN OR DEAD BRANCHES. SOME
INTERIOR TWIGS AND LATERAL BRANCHES MAY BE PRUNED; HOWEVER, DO NOT REMOVE THE TERMINAL
BUDS OF BRANCHES THAT EXTEND TO THE EDGE OF THE CROWN.

TREE PLANTING DETAIL IN ALL SOIL TYPES

NTS

SPECIAL BIDDING NOTE:

CONTRACTOR IS DIRECTED TO BID TREE STAKING AS AN
ADD ALTERNATE, BY PROVIDING AN "EACH" PRICE FOR
STAKING TREES. TREES WILL BE STAKED ON AN
'AS NEEDED' BASIS ONLY!




NOTES:

- USE GREEN ARBORTIE MATERIAL TO ASSURE UPRIGHT TREE POSITION AND STABILITY.
- TIGHTEN ARBORTIE ONLY ENOUGH TO KEEP FROM SLIPPING AND TO ALLOW FOR SOME TRUNK MOVEMENT.
- REMOVE ALL STAKING AS SOON AS THE TREE HAS GROWN A SUFFICIENT ROOT SYSTEM TO OVERCOME STAKING.
STAKES SHALL BE REMOVED NO LATER THAN THE END OF THE FIRST GROWING SEASON AFTER STAKING.

TREE STAKING, 3" CALIPER AND SMALLER, AND 4" TO 6" CALIPER

NTS




STEEL EDGING AT PLANTING BED

NTS


SHRUB PLANTING

NTS



SHOVEL CUT EDGE AT PLANTING BED

NTS




MULCH RING AT TREES

NTS


SOD

NOT TO SCALE



DECOMPOSED GRANITE

N.T.S.



GROUNDCOVER PLANTING

NOT TO SCALE

